

# VE107WNI

Enduraflex™ white, soft, nitrile lining for hydrocarbon oil resistance. FDA compliant.

## SPECIFICATIONS

**FACE MATERIAL DUROMETER, ATMOSPHERIC CURE:**  
50 to 60 A

**PRESSURE CURE:**  
50 to 60

**AVAILABLE GAUGES:**  
1/8", 3/16", 1/4", 4mm, 5mm, 6mm

**SKIVE:**  
Closed or Butt & Cap

**REPAIRS:**  
Repair with original lining.  
See Section 16 – Repair Procedures.

## TYPICAL PHYSICAL PROPERTIES

Tensile Strength PSI	ASTM D412	1300
% Elongation at Break	ASTM D412	500
Durometer	ASTM D2240	55 A
Specific Gravity	ASTM D297	1.30
Adhesion to Metal	ASTM D429	25 LBS

Notes: For the best appearance of the completed rubber lining, always apply plastic side down against the substrate.

Caution: Soft nitrile rubber is susceptible to deterioration by sunlight and oxygen. This is known as ‘weather checking’. Do not expose rubber lining to sunlight, ozone or oxygen.

## CURE METHODS AND TIMES:

Autoclave	1.5 hours at 290°F (143°C)
Internal Pressure	8 hours at 260°F (127°C)
Atmospheric	Step 1 – 6 hours from ambient to 140°F (60°C)
	Step 2 – 4 hours from 140°F (60°C) to 160°F (71°F)
	Step 3 – 24 hours from 160°F (71°C) to 200°F (94°C)

Note: Cure times may require adjustment to compensate for heavy metal thickness, low exterior temperatures or other unusual factors. See Section 14 – Curing Instructions.



# VE107WNI Enduraflex™ white, soft, nitrile lining for hydrocarbon oil resistance.



## STORAGE LIFE FROM DATE OF SHIPMENT

32°F (0°C) to 50°F (10°C)	180 days
51°F (13°C) to 65°F (19°C)	90 days
66°F (21°C) to 75°F (23°C)	60 days
76°F (23°C) to 85°F (30°C)	30 days

Storage temperature must not exceed 85°F (30°C)

## ADHESIVE SYSTEM

1st coat on metal:	Primer P-100
2nd coat on metal:	Intermediate I-100
3rd coat on metal:	201 Tack or 202 Tack
On the rubber:	201 Tack or 202 Tack
On the seams:	202 Tack

\*Each adhesive component requires thorough mixing before application.

## APPLICATOR NOTES

1. Plying up layers of rubber lining thicker than 1/4" could result in the rubber flowing or sagging during cure. Test plate is required to determine flow characteristics.
2. The temperature of the substrate must be greater than 60°F (15°C) prior to applying primer and rubber. Temperatures should not exceed 120°F (49°C).
3. A heated table that warms rubber to approximately 120°F (49°C) is best for application.
4. Strict adherence to adhesive specifications is required. Tack time is critical to the success of the bond.



## DISCLAIMER:

The above guidelines are based on general industry practices and not applicable to all installations. Please contact Blair Rubber Company for specific application instructions. Application methods shall conform to Blair Rubber Company instructions contained in the Engineering & Applicator manual. Deviations from the specifications must be approved in writing by Blair Rubber Company. Data values are approximate and may vary based on installation techniques and atmospheric conditions. As such, data values should be used as general guidelines and are not a legally binding warranty of product characteristics. This document is copyright to and the intellectual property of Blair Rubber Company and may not be copied or distributed without prior consent.